



# Cock Ring

## User Manual




### Specifications

Material	Silicone + ABS
Size	3.03*2.91*1.73in
Net Weight	76.3g
Waterproof	IPX6
Working Frequency	10 frequencies
Working Time	About 30 mins
Noise	<55db




### Button Introduction

- Press the "G" button for 3s to turn on/off, press again to change the frequencies, 10 frequencies change cyclically.



### How to Charge

1. Magnetic charging design;
2. When the charging cable is attached to the 2 magnets on the product, the indicator light up, the button will flash, and the device will start charging.
3. It takes 60 minutes to fully charge and can work continuously for 30 minutes. After fully charged, the indicator light stops flashing.



### Cleaning and Maintain

1. Clean the device with warm water and soap. And then run it through some hot water to wash any traces of soap.
2. Pat it dry with a clean lint-free cloth or a microfiber towel so there is no fluff left on it.
3. Put this product in a dry place, keep the storage environment clean and separate from other materials, and away from Children's contact range.
4. Don't use alcohol to clean the product, for alcohol would corrode the surface of the product and accelerate its aging process.
5. The product waterproof level is IPX6 and not suitable for playing in the water. For its long service life, don't soak it in the water for a long time.

