

# REVEL

## PIXIE

For warranty information, latest products, and news visit us at:  
[nsnovelties.com](http://nsnovelties.com)

### CARE


- \* Turn off device when not in use.
- \* Do not operate the device while charging.
- \* Please follow the charge times indicated in the device specifications.
- \* Wash after each use with liquid anti-bacterial soap and water.
- \* Pat dry with soft, cotton towel and allow to air dry completely.

**Product Dimensions:** 6.81 x 1.26 x 1.46 (in)  
**IPX Rating:** IPX5  
**Battery:** Lithium Ion  
**Charge Time:** Do not exceed 120 minutes  
**Run Time:** 60 minutes  
**Modes:** 8



### PLAY

- \* Press & hold button to power on/off.
- \* Quick press button to cycle through modes.



### CHARGE

- \* The light will blink while the device is charging.
- \* The light will become solid once the device is fully charged.

