REVEL

NOMA

For warranty information, latest products, and news visit us at: $\begin{tabular}{l} \textbf{nsnovelties}. \textbf{com} \end{tabular}$

CARE

- * Turn off device when not in use.
- $\ensuremath{\bigstar}$ Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- $\ensuremath{\bigstar}$ Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with soft, cotton towel and allow to air dry completely.

Product Dimensions: $5.24 \times 1.42 \times 1.42$ (in)

IPX Rating: IPX7

Battery: Lithium Ion

Charge Time: Do not exceed 120 minutes


Run Time: 120 minutes

Modes: 10



PLAY

- * Press & hold button to power on/off.
- * Quick press button to cycle through modes.



CHARGE

- * The light will blink while the device is charging.
- ★ The light will become solid once the device is fully charged.



