

REVEL

WINX

For warranty information, latest products, and news visit us at:
nsnovelties.com

CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with soft, cotton towel and allow to air dry completely.

Product Dimensions: Bullet: 3.31 x 1.18 x 1.18 (in),
Remote: 2.76 x 1.38 x 0.91 (mm)

IPX Rating: Bullet: IPX6, Remote: IPX0

Battery: Bullet: Lithium Ion,
Remote: CR2032

Charge Time: Do not exceed 40 minutes

Run Time: 40 minutes

Modes: 12




PLAY

- * Press & hold button on bullet for 2 seconds to power on/off.
- * Quick press button to cycle through modes.

PLAYING WITH REMOTE

- * To use the remote the bullet must be powered on.
- * Quick press the button on the remote to cycle through modes.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

