

Sugar Pop

BLISS VIBRATING WAND

For warranty information, latest products, and news visit us at:
nsnovelties.com

CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 8.82 x 2.13 x 2.13 (in)

IPX Rating: IPX6

Battery: Lithium Ion

Charge Time: Do not exceed 120 minutes

Run Time: 70 minutes

Modes: 15



PLAY

- * Press & hold **O** button on device for 2 seconds to power on/off.
- * Quick press **M** button to cycle through modes.
- * Quick press **S** button to cycle through speeds.
- * Press & hold **M** and **S** to activate heating mode.



HEAT ————
SPEED ————
MODES ————
ON/OFF ————

CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

