

LED light indicator will remain on when toy is in operation.

To lock/unlock toy hold down both buttons for 3 seconds.

To turn toy off, press either button for at least two seconds. Each motor must be turned off separately. The light will turn off with the motor.