

## **Product Specifications:**

Category: Vibrator User: Women Material: Silicone Finish: PU coating Size: H 141mm W 32mm D: 67mm Battery: Li-polymer battery Voltage: 220mAh Number of Vibrations: 1PCS motor User time: 100mins-100mins Sound Level: Mid

## **CHARGING INSTRUCTIONS**

This vibrator arrives with a partial charge of about 30%, so it is recommended to charge it fully before use, but it does not harm the toy to

use it immediately with its partial charge.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input. Initial charge will take about an hour, and subsequent charges also take

about an hour to complete. The indicator light(s) will flash while device is charging, and remain solid when toy is fully charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 200 minutes of play time on the lowest vibration level, and about 100 minutes of play time on the highest level. The toy's vibrations reduce in intensity as the battery depletes, before stopping completely.

## INSTRUCTIONS FOR USE

INSTRUCTIONS FOR USE
This toy has a one-button control. Press the button
for at least 3 seconds to turn the toy on, then press
the button again more quickly to cycle through 20
different speeds and functions. Press the button
again for at least 3 seconds to turn the toy off.

This toy's motor has a memory function. It will remember the last speed used, and begin with that setting the next time the toy is powered up.