

## **Product Specifications:**

Material: ABS Plastic
Battery: YL801620. 180MAH
Voltage: 3.7V
Number of Vibrations: 10 Vibrations
User time: at least 45 minutes
Sound Level: 50db



## CHARGING INSTRUCTIONS

This vibrating bullet arrives with a partial charge, so it is recommended to charge it fully before use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input. Initial charge will take about 2 hours, and subsequent charges will also take about 2 hours to complete.

The indicator light(s) will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 45 minutes of play time.

This toy comes with a rechargeable battery, operates at DC 3.7V and has a sound level of less than 50db.



This toy has a 1-button control.
Press the button for at least 2 seconds to turn the toy on.
Press again to cycle through 9 vibration frequencies.
Press the button for at least 2 seconds to

Press the button for at least 2 seconds turn the toy off.



