

## **Product Specifications:**

Category: Vibrator Material: silicone and RTV silicone Size: W:1.52", H:8.15",D:1.52" Battery: Lithium ion battery Voltage: 3.7-4.2 V Number of Vibrations: 7 User time: 70-90 MINS Sound Level: ≤60dB/10cm

## CHARGING INSTRUCTIONS

CHARGING INSTRUCTIONS
This vibrator arrives with a partial charge, so it recommended to charge it for at least 30 minutes before use. It does not need to be fully charged before first use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input, which is between the two control buttons on the control panel at the toy's curved handle.

The battery will charge fully in about 180 minutes. The initial charge may be less, and it is not necessary to charge it more than 30 minutes before first use.

The indicator light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 100 minutes of play time with both motors at their highest level of vibration.

This toy operates at a sound level of less than 60db and a

This toy operates at a sound level of less than 60db and a voltage of 3.7V – 4.2V with a lithium battery.

This toy has an easy to use two-button control panel. Each motor is controlled separately by its button, which is the one closest to the shaft it operates.

To turn the main shaft on, press its button for at least 2 seconds. Once it's activated, press that same button again more quickly to cycle through 7 speeds and functions in total. To turn the main shaft motor off, press the button for at least 2 seconds.

To turn the clitoral shaft on, press its button for at least 2 seconds. Once it's activated, press that same button again more quickly to cycle through 7 speeds and functions in total. To turn the clitoral shaft motor off, press the button for at least 2 seconds.

