

Product Specifications:

Material: Silicone + **ABS Plastic** Battery: Rechargeable lithium battery, 602040 420mAH Voltage: 3.7V Number of Funtions: 7F fluctuate function User time: 60 minutes

CHARGING INSTRUCTIONS

INSERT Charger Here

CHARGING INSTRUCTIONS
This vibrator arrives with a partial charge of between 30% - 50%, so it is recommended to fully charge the toy before use.
Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.
Initial charge will take about 1 hour and subsequent charges will take about 2 hours to complete.

The indicator light will flack while device is charging and light up colid when

The indicator light will flash while device is charging and light up solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 90 minutes of play time on the lowest level of vibration with fewer functions active at once, and about 60 minutes on the highest levels with all functions in use.

This toy operates at a sound level of about 55db with an 420mAh battery, at a voltage of 3.7V.

INSTRUCTIONS FOR USE

INSTRUCTIONS FOR USE
This toy has three buttons at its base that operate two separate motors. The middle Power button turns the toy on and off. The top button operates the tapping in the head of the main shaft and the bottom button operates the tapping in the smaller shaft.

Press the middle Power Button for at least 2 seconds to turn the toy on. The light will go on and both motors will enter standby mode. Use this button to turn the toy off by pressing again for at least 2 seconds. Both motors will cease to function (if they are engaged) and lights will turn off.

oft.

When the toy is in standby mode, press the top Head Tapping button for at least 2 seconds to engage the tapping function motor at the head of the main shaft. Press the button again more quickly to cycle through 7 tapping speeds. Hold this button for another 2 seconds to turn the Head Tapping motor off.

Till --

USB RECHARGEABLE

When the toy is in standby mode, press the bottom Rabbit Tapping button for at least 2 seconds to engage the tapping function motor in the clitoral stimulator shaft. Press the button again more quickly to cycle through 7 tapping speeds. Hold this button for another 2 seconds to turn the Rabbit Tapping motor off.

Please note, if any or all of the motors are left on accidentally, they will turn off automatically on their own after 10 minutes.