

<http://www.evolvednovelties.com/>

EVOLVED
Love is Back



Product Specifications:

Material: Silicone + ABS
Battery: Product:
Rechargeable Lithium Polymer
battery, 3.7V/240mAh
Remote: Rechargeable Lithium
Polymer battery, 3.7V
Voltage: 3.7V
Number of Vibrations: 9
User time: 35~70 minutes
Sound Level: <40dbs

CHARGING INSTRUCTIONS: This vibrator arrives with partial charge, so it is recommended to charge fully before use.
Connect the USB end of the charging cable into the part of your power source and the other end onto the magnetic charging pins located below the Power Button at the base of the toy's thicker end. Initial and subsequent charges will take about an hour to complete.
The indicator light will flash on toy while device is charging and become solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.
Charge lasts for about 70 minutes of play time on the lowest level of vibration, and about 35 minutes on the highest level.
This toy operates at a sound level of less than 40db with a 240mAh lithium battery at a voltage of 3.7V.
The remote control is also rechargeable with the same USB and cable. Its charging pins are on the back panel.

INSTRUCTIONS FOR USE

This toy can be operated directly with the button at the base of its thicker end, or with the two buttons on its remote control. Important note: You cannot turn the toy ON or OFF with the remote control, but you can put it in standby mode. Use the button directly on the toy to power it on and off.

OPERATE WITH TOY DIRECTLY

Press the Power Button at toy's base for at least 3 seconds to turn toy on.
Press the Power Button again more quickly to cycle through 9 different vibration speeds and functions.

Once the toy is on, you may power on the remote and use its buttons to operate vibrations and functions separately.

To turn toy off, press Power Button for at least 3 seconds.

OPERATE WITH REMOTE CONTROL: Once the toy is on (by using the button at its base), press the Power Button on remote for at least 3 seconds to turn on the remote control.

Use the Function Button on remote to cycle through 9 different vibration speeds and functions.

Press the Power Button again for 3 seconds to turn off the remote control, which will put the toy in

standby mode. The toy must be turned off directly with its own button. However, after 20 minutes in standby mode, the toy will power off automatically by itself.

ATTACH USB
CHARGER
TO PRONGS

USB RECHARGEABLE

