

<http://www.genderx.com/>

**GENDER** X



**Product Specifications:**

Material: Silicone+ABS

Battery: Lithium battery

Voltage: 3.7V

Number of Vibrations:

12 models

User time: 40-75 minutes

Sound Level: Less than 60DBS

**CHARGING INSTRUCTIONS**

It is recommended to fully charge this toy before first use, and charge for 10-20 minutes after use.

To charge, connect the USB plug into the USB port of your computer or other output and the DC charger into input at the side of the toy, just under ring handle.

Initial charge will take about an hour and subsequent charges will take between 10 and 40 minutes to complete.

The blue indicator light will flash while device is charging and turn off when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 40 minutes of play time at the highest level of vibration and about 75 minutes at the lowest level.

This toy operates at a sound level of between 60db with a rechargeable lithium battery at 3.7V.

**INSTRUCTIONS FOR USE**

This toy has a convenient 1-button control at the base of the finger ring.

To turn toy on, press the Power Button for at least 1.5 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency.

Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 12.

To turn toy off, press Power Button for at least 1.5 seconds.



INSERT  
CHARGER  
HERE



**USB RECHARGEABLE**