

<http://www.genderx.com/>

**GENDER** X



**Product Specifications:**

Material: Silicone+ABS

Battery: Lithium battery

Voltage: 3.7V

Number of Vibrations: 12

User time: 40-50 minutes

Sound Level: 60DBS

**CHARGING INSTRUCTIONS**

This vibrator arrives with a low partial charge, so it is recommended to charge fully before use.

To charge, connect the USB plug into the USB port of your computer or other output and the DC charger into the port at the side of the toy's handle.



Initial charge will take about an hour and subsequent charges will take between 10 - 40 minutes, depending on use.

The indicator light will flash while device is charging and turn off when toy is fully charged.

There is no danger of battery damage by overcharging but it's recommended not to overcharge for long periods of time.

Charge lasts for about 40 minutes of play time at the highest level of vibration and about 50 minutes at the lowest level.

This toy operates at a sound level of less than 60db with a rechargeable battery at 3.7V.

**USAGE INSTRUCTIONS**

This toy has a convenient 1-button control at the side of its looped handle.

To turn toy on, press the Power Button for at least 3 seconds. The lights will turn on and toy will begin vibrating at its first lowest frequency.

Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 12.

To turn toy off, press Power Button for at least 3 seconds.

**USB RECHARGEABLE**