

<http://www.evolvednovelties.com/>

EVOLVED
Love is Back



Product Specifications:

Material: Silicone+ABS
Battery: Rechargeable
Li-ion battery 300mAh
Voltage: 3.7V
Number of functions: 10
User time: 90mins on the
highest level. 100mins
on the lowest level.
Sound Level: <60DB

CHARGING INSTRUCTIONS

This toy arrives with a partial charge of about 30%. It's important to use up this initial charge before charging in order to achieve the best battery longevity.

To charge, plug in the toy's charging base by connecting its USB port with the port on your computer or other DC source with the included USB cable. Then place the toy on top of the charging base, making sure that the magnetic pins connect.

The indicator light will flash while device is charging and turn solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Initial and subsequent charges will take about 90 minutes to complete.

Charge lasts for about 90 minutes of play time at the highest level of vibration and about 100 minutes at the lowest level.

This toy operates at a sound level of between 60db with a rechargeable 300mAh lithium battery at 3.7V.



ATTACH TOY
PRONGS
TO USB
CHARGER
BASE

INSERT USB
CHARGER
TO CHARGING
BASE HERE

USB RECHARGEABLE

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at its base.

To turn toy on, press the Power Button for 2 to 3 seconds. The light will turn on and toy will begin flicking at its first lowest frequency.

Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 10.

To turn toy off, press Power Button for 2 to 3 seconds.