

<http://www.evolvednovelties.com/>

EVOLVED
Love is Back



Product Specifications:

Material: Silicone+metal
Battery: 701225 / 130mAh
Battery Voltage: 3.7V
Number of vibration: 3 speeds
+7 vibration modes
User time: 1 hour
Sound Level: ≤40db

CHARGING INSTRUCTIONS

This toy arrives with a partial charge, so it is recommended to charge completely before use.

To charge, connect the USB plug into the USB port of your computer or other output and the DC charger into the port at the back of the toy's base.

Initial and subsequent charges will take about 35 minutes to complete.

The white indicator light will flash while device is charging and turn off when toy is fully charged.

There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 1 hour of play time at the highest level of vibration and about 75 minutes at the lowest level.

This toy operates at a sound level of about 40db or less with a rechargeable 130mAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at the side of its base.

To turn toy on, press the Power Button for at least 3 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency.

Once the toy is on, press the Power Button again, a single time for each new speed or function for a total of 10.

To turn toy off, press Power Button for at least 3 seconds.



USB RECHARGEABLE