

<http://www.genderx.com/>

GENDER X



Product Specifications:

Material: Silicone & ABS

Battery: 500mAh

Voltage: 3.7V

Number of Vibrations: 10

Vibrating , 10 Thrusting

User time: About 2 hours

Sound Level: Less than 50 dB

CHARGING INSTRUCTIONS

This toy arrives with a partial charge of between 30% - 50%, so it is advised to fully charge it before first use.

To charge, connect the USB cable to the port of your computer or wall outlet adapter and the other end into the toy's port at the base of the main shaft. Initial charge will take about 1 hour, and subsequent charges will take about 2 hours to complete.

The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 2 hours of play time on the lowest level of vibration and about 90 minutes on the highest level.

This toy operates at a sound level of less than 50db with a rechargeable 500MAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at its base.



To turn toy on, press the button for about 3 seconds. The light will turn on and toy will begin vibrating and thrusting at its first lowest frequency. Both motors work together.

Press the button again more quickly to cycle through a total of 10 thrusting speeds & 10 speeds of vibration.

To turn toy off, press button for about 3 seconds.