

<http://www.genderx.com/>

GENDER X



Product Specifications:

Material: Silicone
Size: L: 10.47inch D:2.09inch
Battery: 2000mAh
Voltage: 5V
Number of Vibrations: 2
motors , 10 vibration patterns
each motor
User time: 2hours
Sound Level: Less than 50dB

CHARGING INSTRUCTIONS

This toy arrives with a partial charge, so it is recommended to charge fully before first use.

To charge, connect the USB plug into a power source at one end, and the DC charger plug into the port at the middle of the toy's handle.

Initial charge will take about 2 hours. Subsequent charges will take about 3.5 hours to complete.

The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging but it's recommended not to overcharge for long periods of time.

Charge lasts for about 1.5 hours of play time on the highest level of vibration and about 2.5 hours at the lowest level.

This toy operates at a sound level of less than 50db with a rechargeable 2000mAh lithium battery at 5V.

INSTRUCTIONS FOR USE

This toy has a 2-button control at the side of its handle. To turn toy on, press the bottom (power) button for at least 2 seconds. The light will turn on and both motors will be in standby.

Press the bottom button again more quickly to cycle through 10 vibrating speeds and functions in the tail end of the wand vibrator.

Once the toy is in standby, press the top button to cycle through 10 speeds and functions in the wand head, and press for at least 2 seconds to put this motor back in standby.

To turn toy off completely, press bottom (power) button for at least 2 seconds.

