

## **Product Specifications:**

Material: Silicone & ABS Battery: Li - battery, 802040, 600mAh Voltage: 3.7V

Number of Vibrations: 10 User time: 60 - 75 Minutes Sound Level: ≤60dB

## CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge, so it is recommended to charge before first use. Initial charge will take about an hour, subsequent charges will take about 90 minutes to complete.

Connect the USB plug into a power source and the other end of the DC charger connect the USB ping into a power source and the other end of the DC charger onto the magnetic charging pins located at the back of the toy's handle. The indicator light will flash while device is charging and turn solid when toy is fully charged. There is no danger of battery damage by overcharging but it's not recommended to overcharge for long periods of time.

Charge lasts for about 75 minutes of play time on the lowest level of vibration, and about 60 minutes on the highest

This toy operates at a sound level of about 60db with a 600mAh lithium battery at a voltage of 3.7.

## INSTRUCTIONS FOR USE

ATTACH USB CHARGER TO PRONGS

This stroking vibrator is operated with a 3-button panel located on the front of the handle. The center button powers the toy on, the top button operates the stroking in the head and the bottom button operates the

vibration in both shafts simultaneously. Turn the toy on by pressing the center button for about 3 seconds. The LED light will turn on and both the stroking

and vibration motors will be in

and vibration motors will be in standby.
The top button controls the vibration motor in the main and small shafts.
Once the toy is on, click this button to cycle through a total of 10 vibration speeds and patterns.
The bottom button controls the stacking metion in the head. Once

stroking motion in the head. Once the toy is on, click this button to cycle through a total of 10 vibration speeds and patterns. Turn the toy off by pressing the center button for about 3 seconds.

**USB RECHARGEABLE**