

<http://www.genderx.com/>

GENDER X



Product Specifications:

Material: Soft Solid Silicone
Battery: Li-ion battery
Battery Voltage: 3.7V
Number of Vibrations: 10
User time: 60 - 90 Minutes
Sound Level: ≤60DB

CHARGING INSTRUCTIONS

This toy arrives with a partial charge, so it is recommended to charge it fully before first use.

To charge, connect the USB plug into a power source and the DC charger into the port at the side of the base of the toy.

Initial charge will take between 4-6 hours and subsequent charges will take between 2-3 hours to complete.

The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 90 minutes of play time on the lowest level of vibration and about 60 minutes on the highest level.

This toy operates at a sound level of less than 60db with a rechargeable lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a 1-button control at its base that controls the motor in the shaft.

To turn toy on, press the button for at least 1.5 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency.

Once the toy is on, press the button again, a single time for each new speed or function for a total of 10.

To turn toy off, press button for at least 1.5 seconds.

