

## **Product Specifications:**

Material: Silicone & ABS Battery: Polymer lithium 320Mah Voltage: 3.7V

Number of Vibrations: 10 User time: 45 - 60 Minutes Sound Level: <40Db

CHARGING INSTRUCTIONS
This toy arrives with full charge, so it is not necessary to charge before first use. Initial charge will complete in about 90 minutes, subsequent charges in about 30 minutes. Connect the USB cable to a power source and its DC plug into the port at the bottom of the toy's handle. The light flashes when the toy is charging and turns solid when complete.

Battery charge lasts for about 1 hour on the lowest frequency, and 40 minutes on the highest frequency. This toy operates at a sound level of less than 50db with a lithium battery at 3.7V.



- INSTRUCTIONS FOR USE
  1. Find the 1-button control panel at the front of the toy's handle and press for 2 seconds to turn the toy on. The button will light up and begin in standby.
- 2. Press the same button more quickly to cycle through 10 speeds and patterns.
- 3. Press the button for 2 seconds to turn the toy off. The light will turn off and vibration with cease in both motors.

## **USING REMOTE**

- 1. When toy is in standby press the button to cycle through 10 vibration speeds and patterns.

  2. Hold down button for 2 seconds
- to stop vibration in both motors and return toy to standby.