

Product Specifications:

Material: Silicone Battery: Li-ion

Voltage: 3.7V

Number of Vibrations: 10 User time: 40 - 60 Minutes Sound Level: <50 db

CHARGING INSTRUCTIONS

This toy arrives with full charge, so it is not necessary to charge before first use. Initial charge will complete in

about 90 minutes, subsequent charges in about 30 minutes. Connect the USB cable to a power source and its DC plug into the port at the bottom of the toy's handle. The light flashes when the toy is charging and turns solid when complete. Battery charge lasts for about 1 hour on the lowest frequency, and 40 minutes on the highest frequency. This toy operates at a sound level of less than 50db with a lithium battery



INSTRUCTIONS FOR USE

1. Find the 1-button control panel at the front of the toy's handle and press for 2 seconds to turn the toy on. The button will light up and the toy will be in standby.

2. Press the same button more quickly

to cycle through 10 speeds and

at 3.7V.

patterns.
3. Press the button for 2 seconds to turn the toy off. The light will turn off and vibration with cease in both

USB RECHARGEABLE motors.