

Product Specifications:

Material: Silicone & ABS Battery: 902025 400mAH Voltage:3.7V Number of Vibrations: 8 User time: 60 - 90 Minutes Sound Level: ≤55dB

CHARGING INSTRUCTIONS

It is recommended to charge this toy fully before first use. To charge, connect the USB plug into a power source and the charging end onto the magnetic pins at the side of the toy's base. The indicator light will flash while device is charging and stay constant when toy is fully charged. Initial charge will take about an hour and subsequent charges about 2 hours to complete.

Charge lasts for 1 hour of playtime at the highest speed and 90 minutes at the lowest speed. This toy operates at a sound level

of less than 55db with a rechargeable 400mAh lithium battery at a voltage of 3.7V.



INSTRUCTIONS FOR USE

1. This toy has a 1-button control panel at the side of its base. 2. Press the button for 2 seconds to turn toy on. The button will light up and the motor will begin vibrating at its lowest frequency. 3. Press the button again more quickly to cycle through 8 vibration speeds and patterns. 4. To turn toy off, press button for 2 seconds. The light will turn off and all vibration will cease.

USB RECHARGEABLE